


Daylight Savings Update PIX-3000



1. Remove the cover of the clock, and press the **PROGRAM** button.
2. Press the **CHANGE** button until the cursor reaches **BEGIN DAYLIGHT SAVINGS** and then press the **ENTER** button.
3. You will see the beginning daylight savings date displayed with the year flashing.
4. Press the **CHANGE** button until the correct Year is displayed and then press **ENTER**.
5. Next the Month flashes press **CHANGE** until the proper month appears and then press **ENTER**.
6. Press the **CHANGE** button until the proper Day is displayed and then press **ENTER**.
7. Finally all of the data you have entered flashes for you to verify the new Daylight Savings date, press **ENTER** to accept.
8. Repeat these steps for **END DAYLIGHT SAVINGS**, and then press **PROGRAM** again to exit programming mode.

Buffalo Time Clock, Inc.

1942 Colvin Blvd.
Tonawanda, NY 14150
Phone: 716-831-8044 Fax: 716-834-4136